

# heatfast

## Type HF6IBC-3 3KW IBC Heating Jacket

- Teflon/Polyester Insulation
- IP40 Protection
- 2 x 1500W Power Circuits
- Thermally Insulated
- Adjustable Quick Release Buckles
- 0 to 90°C Thermostat
- Bespoke Sizes to Order
- 4 Metre Power Cable
- Ex-stock
- 230V / 110V



- Quality Assured
- Dedicated Design
- Cost Effective
- Express Delivery



ISO 9001:2008  
FM 558985

UL and VDE approved manufacturing facilities

# heatfast

## Type HF6IBC-3 3KW IBC Heating Jacket

### Advantages:

Providing an efficient heating system the HF6IBC-3 jackets are ideal for reducing the viscosity of a variety of products including fats, oils and foodstuffs, to enable the decanting of the product into smaller containers or process lines.

Used throughout the world by a multitude of industries from pharmaceutical to chemical, cosmetic to food, the HF6IBC-3 heater is the ideal solution for heating liquid materials stored in intermediate bulk containers.

### Construction:

Suitable for all types of IBC this heater jacket has quick release adjustable buckles for ease of installation and removal and is designed with upper and lower heat zones, each with separate thermostatic control. This allows for the upper heating zone to be switched off once the content level has fallen below half way.

Unlike expensive conventional ovens, the heater jacket allows the IBC to be heated at its point of use. Or once heated the IBC can be moved with the jacket in position and still maintain the temperature for longer thanks to the high efficiency thermal insulation. With 1500 Watts per zone and optional insulation lid the heater jacket offers a cost effective way of heating IBC's.



### Technical Data:

Size:	1000mm x 4400mm (3900mm heated length)
Rating:	230 / 110 Volts 2 circuits each 1500 Watts
Temp. Control:	0°C to 90°C

HF6IBC23B	-	3KW 230V 0-90°C Stat
HF6IBC13B	-	3KW 110V 0-90°C Stat

### Health and Safety:

All HF6IBC-3 container heaters are manufactured to conform to the EEC low voltage and EMC directives and CE marked accordingly. It is advised that power to the heater jacket be disconnected when the container is either empty or being filled, or upon installation or removal of the heater itself. It is recommended that the unit be operated in a dry environment with the container vented to avoid build up of internal pressure.

### Customer Support:

T&D have been providing process heating solutions since 1985. For detailed product information please visit [www.heatingandprocess.com](http://www.heatingandprocess.com) or contact our technical sales team.